Executive Order VR-101-B

Exhibit 1

Figure 1A

Phil-Tite Phase I Vapor Recovery System Equipment List

Component Name	Manufacturer	Model Number
Spill Container Debris Bucket	Phil-Tite Phil-Tite Phil-Tite	85000 Series PP 1005 TB (product) (required) PP 1005 TBP (vapor) (optional)
Gasoline Hand Pump Rotatable Phase I Adaptors	Phil-Tite Phil-Tite Phil-Tite	EP-400-VB (optional) SWF-100-B (product) SWV-101-B (vapor)
Phase I Vapor Riser Offset Riser Adaptor Spill Container Cast Lid	Phil-Tite Phil-Tite Phil-Tite	M-6050 (optional) M/F4X4 85011
Drop Tube	OPW	61-T (various lengths)
Dust Caps	Morrison Brothers Morrison Brothers	305C (product) 323C (vapor)
Pressure/Vacuum Vent Valve	Husky	Model 4885, 2-Inch Threaded
Extractor Fitting	Universal OPW	V421 Series 233 Series
Ball Float Vent Valve	Universal OPW	Model 37 Series Model 53 VM Series
Tool Kit for Rotatable Adaptors and Spill Containers	Phil-Tite	T-7043
Tank Gauge Port Components *	Ever-Tite	4097AGBR (Threaded Adaptor) 4097MBR (Double Handle Cap)

^{*} Tank gauge port components, other than those listed above shall <u>not</u> be installed after September 1, 2002. Tank gauge port components installed prior to September 1, 2002, shall be allowed to remain in use for the remainder of their useful life.

Figure 1B

The following components may not be installed as new or replacement parts after September 1, 2002. These components, if installed prior to September 1, 2002, may remain in use for remainder of their useful life.

Component Name	Manufacturer	Model Number
Drop Tube	EBW Emco Wheaton	782-204 (various lengths) A0020 (various lengths)
Extractor Fitting	EBW Emco Wheaton	3XX Series A0079 Series